

Disposable TV Remote Covers

Made in the U.S.A.

TV remotes can be one of the most frequently touched items in a room - and one of the most difficult object to clean and sanitize!

PanSaver's disposable tv remote covers help reduce the risk of cross contamination between guests while making it easier to keep it clean.

- Great for hotels, hospitals, nursing homes, restaurants, and classrooms
- Clear plastic means the remote stays sealed in the bag during use!
- Adhesive strip creates a snug fit on the remote. Tear notch on the bag makes it easy to remove the remote to change the cover.
- Made of the same film used in medical and dental sterilization packaging.
- Protects electronics from harsh cleaning chemicals.
- 4" x 9.5" bag fits most standard remotes. Custom sizes are available.




Contact us today for pricing and samples.

Description	ltem #	Case Pack
4" x 9.5" Disposable TV Remote Cover	42481	10-100 count packs

PS Protective Products

part of the PanSaver family of products info@pansaver.com 267-498-4000 pansaver.com





How to Use Disposable TV Remote Covers

- 1. Open bag with the white tape facing up.
- 2. Turn remote over (back facing up) and slide the remote into the bag.
- 3. Remove the white tape strip.
- 4. Fold the bag up until the bottom of the bag fits snugly against the bottom of the remote.
- 5. Press down on the adhesive to seal



- 1. Locate the tear notch at the top of the bag (opposite the adhesive end).
- 2. Grasp either side and rip open the bag.











PS Protective Products

part of the PanSaver family of products info@pansaver.com 267-498-4000

pansaver.com